

Visual Merchandising (Creo™)

Applicable Products:

Saddle Bracket (CRSD)

1. Insert the glide screw/knob rest assembly into the channel of the crossbar or upright, then loosely tighten the knob to prevent it from slipping.
2. Slide the saddle bracket over the knob rest, then fully tighten the knob to firmly secure the saddle bracket position.

