

Visual Merchandising (Creo™)

Applicable Products:

Retractable Crossbars Bottom
(CRPC)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Press crossbar into base upright channels (Make sure crossbar is positioned as shown) (fig. A & B).
2. Slide uprights over base uprights and tighten upright knob to secure (fig. C).
3. Slide pocket arm glides into upright channels and tighten to secure (fig. D). Repeat 2x.
4. Pull graphic out of crossbar canister (fig. E) and insert unnotched end of pocket arm over pocket glide (fig. F).
5. Press notched end of pocket arm over opposite pocket arm glide to secure (fig. G).

