

Visual Merchandising (Creo™)

Applicable Products:

Retractable Crossbars Top
(CRPC)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Slide pocket arm glides into upright channels (fig. A & B) and tighten to secure. Repeat 2x.
2. Press crossbar into upright channels (Make sure crossbar is positioned as shown) (fig. C & D).
3. Insert unnotched end of pocket arm over pocket glide (fig. E).
4. Press notched end of pocket arm over opposite pocket arm glide to secure (fig. F).
5. Slide cones over upright and tighten to secure (fig. G).

