

# Visual Merchandising (Creo)

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

- 1. Insert glides into upright channel (fig. A).
- 2. Tighten knobs onto glides to secure location of frame (fig. B)

**Applicable Products:**

- Swivel Frame
- CRSV0
- CRSV1
- CRSV2
- CRSV3

