

Visual Merchandising (Creo™)

Applicable Products:

Center Garment (CRCG)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Insert puck glides into upright channel. Slide pucks to desired location (fig. A).
2. Align brackets over pucks (fig. B & fig. C) and tighten to secure.
3. Rest garment pole over bracket notches to complete unit assembly (fig. D & E).

