

# Visual Merchandising (Creo)

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

1. Insert puck glide into crossbar channel (fig. A).
2. Slide glide to desired location (fig. B).
3. Align hole on waterfall bracket with puck glide (fig. C).
4. Slide waterfall bracket over glide (fig. D).
5. Screw puck onto glide and tighten to secure (fig. E).

## Applicable Products:

Waterfalls (CRWC5)  
Waterfalls (CRWC7)

