

# Visual Merchandising (Creo™)

## Applicable Products:

Hook & Loop Bar (CRSB)

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

1. Insert puck glides into upright channel. Slide pucks to desired location (fig. A).
2. Align bar bracket with puck (fig. B).
3. Sandwich bar bracket in between upright and puck and tighten puck to secure (fig. C).
4. Attach graphic to hook & loop bar (fig. D).

