

Visual Merchandising (Creo™)

Applicable Products:

Pocket Arm Two Section
(CPRA)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Slide pocket arm glide into upright channel (fig. A & B) and tighten to secure.
2. Slide graphic over pocket arm. Insert unnotched end of pocket arm over pocket glide (fig. C).
3. Press notched end of pocket arm over opposite pocket arm glide to secure (fig. C & D).

