

# Visual Merchandising (Creo™)

**Applicable Products:**

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

Pamphlet Holder (CRPH)

1. Slide glide screw down Creo upright. Place the bracket anywhere vertically along upright channel and tighten knob rest to secure (fig. A).

