

# Visual Merchandising (Creo™)

## Applicable Products:

Literature Holder (CRLF)

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

1. Insert knob rest into upright channel. Slide knob rest to desired location (fig. A).
2. Slide literature holder bracket onto upright and tighten knob rests to secure (fig. B).

