

# Visual Merchandising (Creo)

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

1. Slide Glide Screw down Creo upright. Place the bracket anywhere vertically and tighten Knob Rest to secure (fig. A).

## Applicable Products:

Mirror (CRAM)



(A)

