

Visual Merchandising (Creo™)

Applicable Products:

Pegboard

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

Creo Frame

1. Slide puck glide into crossbar channel (fig. A). **Repeat 6x** (3 glides per crossbar).
2. Press bottom crossbar into upright channel (fig. B & C). Slide second upright over the first and tighten knob to secure (fig. D & E).
3. Press top crossbar into upright channel (fig. F & G). Screw cone over upright to secure unit (fig. H & I).

Pegboard

1. Align pegboard brackets over puck glides (fig. J & K) and screw puck onto glide to secure bracket (fig. L). **Repeat 6x**.
2. Align pegboard holes with bracket holes (fig. M). Screw pegboard onto brackets to secure unit (fig. N & O).

