

Visual Merchandising (Creo™)

Applicable Products:

Podium (CRPK3)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Press bottom shelf crossbar into base upright channel (fig. A).
2. Slide uprights over base uprights and tighten knob, using cone top as a tightening tool (fig. B).
3. Press top shelf crossbar into upright channel (fig. C).
4. Slide cone over upright and tighten cone to secure (fig. D).
5. Wrap hook and loop graphic around podium.

