

Visual Merchandising (Creo™)

Applicable Products:

Creo Slatwall

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Press bottom crossbar into base upright channels (fig. A-1).
2. Place uprights (with slatwall channel facing towards the inside) over base uprights (fig. A-2) and tighten upright knobs to secure (fig. A-3).
3. Slide slatwall sections down the slatwall channels and interlock them as shown (fig. A-4).
4. Add additional uprights/slatwalls as needed (fig. B).
5. Press top crossbar into upright channels (fig. C-1). Place cones on top of uprights and tighten cones to secure unit (fig. C-2).

NOTE: Unit shown below may differ from your model, but assembly instructions remain the same.

