

Wall Mount Upright - CRUW (Creo™)

1. Mount bottom bracket against wall using screws provided, approximately 6" above the floor.
2. Slide upright through bracket and allow upright to rest on the floor.
3. Slide upper bracket over upper bracket over upright and mount to wall using screws provided, approximately 6" below the top of the upright.

NOTE: Model shown below may differ from your model. Although the number of upright sections may change, assembly instructions remain the same.

