

# Visual Merchandising (Creo™)

## Applicable Products:

Plasma Bracket (CRVA)  
Plasma Bracket (CRVX)

**NOTE: Most upright components must be installed before completing unit assembly.  
End user determines component location.**

1. Insert puck glides into upright channel (fig. A).
2. Slide pucks to temporary location (fig. B).
3. Hook plasma bracket over pucks (fig. C).
4. Tighten pucks to secure unit (fig. D).
5. Mount TV to bracket.

