

Visual Merchandising (Creo™)

Applicable Products:

iPad Holder (CRIH)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Insert knob rests into upright channels; one knob rest per side (fig. A & B).
2. Remove acrylic cover using small tamper-proof key provided. Place tablet inside and reassemble unit (fig. C). If ball joint loosens on back, use the large tamper-proof key to retighten it securely.
3. Hook saddle bracket over knob rests and tighten knob rests to secure unit (fig. D).

