

Visual Merchandising (Creo)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. To Insert (or remove) iPad: first use key provided to unscrew 4 screws, then detach front face of iPad Holder. Once in place, slip cover back on and tighten the 4 screws. (fig. A).
2. Insert puck glides into upright channel and tighten at desired location (fig. B).
3. Hook iPad Holder bracket over pucks and tighten pucks to secure (fig. C).

Note: The iPad Holder swivels but can be mounted stationary using additional key provided.

Applicable Products:

iPad Holder (CRIH)

