**CBR Series** 

- 1. Insert base crossbars in between bases and screw together (larger holes on base should face towards the outside) (fig. A).
- 2. Press middle uprights into base. Make sure push buttons face towards the inside and click securely into place (fig. B).
- 3. Insert top uprights into middle uprights. Make sure push buttons face towards the inside and click securely into place (fig. C).
- 4. Insert crossbars in between uprights and screw securely into place (fig. D).
- 5. Slide graphic over frame like a pillowcase and zipper at bottom to close.

