

EasyOpen SnapFrame™ - ME Series, Knocked Down

1. Align a pair of corner brackets back to back and slide them into the frame assembly as shown.
2. Tighten the first set screw so that the corner brackets are secure. Then, slide the corner brackets into the side frame assembly.
3. Screw the second set screw into the corner brackets and tighten securely.
4. (For drywall) Align drywall screws with frame slot and screw into drywall anchors to secure.
(For slatwall) Align screws with frame slot and screw into slatwall bracket to secure.
5. Place graphic in frame and snap frame flaps over graphic to secure.

