

# Perfex™ CounterTop Frame - PX1T, PX2T, PX3T

1. Attach the stand-off to the frame using the threaded rod on the bottom of the frame.
2. Connect the base to the stand-off using the screw provided.
3. Insert the graphic.

NOTE: Model shown below may differ from your model, but assembly instructions remain the same.  
DO NOT discard small stand-off tubing when unpacking.

