

# Standoff (SNSO)

1. Insert graphic into open SnapGraphic™ and clamp into place (fig. A).
2. SnapGraphic™ doesn't close well until graphic insertion.
3. Slide SnapGraphic™ into aluminum shroud.
4. For Standoff Models (Fig.B):
  - Drill hole on wall.
  - Push in wall anchor.
  - Screw standoff into anchor.
  - Detach front Z bracket from standoff, insert into SnapGraphic channel.
  - Align with standoff mounted to wall and use 4 screws provided to secure.

## Applicable Products:

SN1, SN2

