

Charisma SEG Air - XAIR - Tool Free

Each tube end is marked with a number sticker, connect 1 to 1, 2 to 2, 3 to 3, etc

- 1. For Free Standing Unit ONLY:** Find the bottom frame section with 2 holes at each end. Place bases in line with the 2 inner holes at each end of the extrusion. Use the LONG knobs provided to come down through the bottom extrusion into the threaded holes of bases.
- Connect the side sections to the bottom section, by inserting the underside tab fully into the adjacent section. Hook the swiveling bar of the latch onto the hook of the adjacent frame side, then push the latch down until you hear or feel it snap closed. Repeat this step for the opposite side.
- 3A: If included with your frame, insert the 3/8" diameter support rod into the center hole of the bottom side (or vertical sides depending on your frame).** **3B:** Repeat step 1 for the connecting top side of frame. **3C: If center support rod included, insert the top end of the center support rod into the center hole of the top side, before fully locking the latches.**
- 4. FOR WALL MOUNTING ONLY:** Use screws and anchors appropriate to your wall surface to mount. Install mounting brackets to wall for top frame section. Place frame over those mounting brackets, then secure with additional mounting brackets for the sides.
- To install the graphic, take the corner with the pull tag on it and press about 6"-10" of silicone into the frame channel corner A. Repeat for the opposite corner B. Repeat for the next corner C. Lastly, repeat for the final corner D.
- After all corners are pressed in, press the silicone into the frame channel at the mid-points on all four sides.
- Press silicone into frame evenly between the corner and midpoints. This prevents the graphic from bunching up or stretching too much and will ensure a smooth and tight fit. Repeat steps 6-8 on the second side.
- To remove the graphic from the frame, simply pull up on the pull tag.

