

Convex Poster SignHolder™ - VX1292

1. Connect uprights to the base: The base is the larger steel plate with guide pins that will be facing upward. Find the bottom of the uprights which is the side of the upright with a hole ~8" in from the end. Insert the flat-head screws provided, into the cone-shaped holes in the bottom of the base and thread the screws into the uprights. Make sure to fully tighten. Repeat for the second upright.
2. Connect the V-brace: The V-brace is provided with stand. The vertical holes of the V-brace align with the pre-drilled holes in the uprights, and the center holes of the V-brace aligns with the center holes of the base itself. Use the short screws provided to attach the V-brace to the base and uprights.
3. Connect the top plate to the uprights: Carefully lean the frame onto the floor as shown. The top is the smaller steel plate and has pins which should face down into the uprights. Carefully place the top plate at the end of the uprights and thread the long round-head screws provided, through the top plate into the top of each upright.
4. With the stand still leaning on the floor as shown, Align the graphic flat above the stand so it can be slid in from the top plate.
5. Insert the graphic from the top edge into the upright channel grooves. If you have an issue fitting the graphic in, you may need to rotate the upright slightly or compress the graphic slightly to curve it. Once the graphic is in a few inches, evenly PULL the remaining graphic into the side channels. When there are only a few inches left, you may need to push the graphic from the top to complete installation.
6. Carefully rotate the unit taking care not to dislodge the first graphic. Repeat steps 4 and 5 for the second graphic, being careful not to push out the 1st graphic (not shown).
7. To remove the graphic, carefully tilt the stand down and rest it on the floor. Use the holes on the top to first lift the graphic upward, then pull the graphic out.

