

# PortaPole™ - VCST3 Series

1. Slide bottom clamp holder upward onto the bottom upright and tighten knob to secure.
2. Attach upright to base using screw provided.
3. Slide top clamp holder onto the upright and tighten knob to secure.
4. Loosen collar knob, slide upright upward to desired height, then tighten collar knob to secure upright.
5. Visually check to ensure clamps are aligned vertically, adjust if needed (not shown).
6. Open clamps to insert graphic (not shown).

