

Visual Merchandising (Creo™)

Applicable Products:

Angle Backs (CRUK)

MAIN STRUCTURE ASSEMBLY INSTRUCTIONS
SEE ATTACHED PAGES FOR DETAILED INSTRUCTIONS

- 1. Insert Rest Puck and Glide into channel of Upright. Tighten slightly to temporarily secure position.
- 2. Fasten Graphic to Angle Backs using Plain Puck Screws.
- 3. Place Angle Backs over Rest Pucks and tighten Rest Puck to secure.

