## **Instructions**

Testrite Visual

- 1. Start with the flat steel base. Identify the bottom side, which has a cone shaped space for the screw
- 2. Use the large cone shape screw, insert it up through the cone shaped hole in the base, and use a Phillips head screw driver to attach the base into the bottom of the upright pole. Ensure screw is tight, but don't over-tighten.
- 3. Use a Philips head screwdriver along with the small screws to slowly and carefully attach the electronic price tag holder to the mounting plate, using the existing holes in the back of the electronic price tag. Do not over-tighten the screws.
- 4. Place the angled mounting plate on top of the upright, hold it in place with one hand, and use the other hand to attach the knob through the mounting plate into the top of the upright pole. Adjust the top mounting plate so the plate faces one of the sides of the base and tighten the knob.

TT-2129

