

Perfex Pedestal SignFrame - PA Series

1. Align bottom holes of upright with holes on base stem, then connect upright to base using the 2 slightly longer screws.
2. Use the two remaining screws to connect the frame to the upright.
3. Insert the graphic.
4. For the -TP Telescopic upright units, open the lever, raise the upright to the desired height, then close the lever to secure the height position

