

# Simple Standee™ - DEE Series

1. Assemble the uprights by aligning the upright sections, then allowing the rubber shock-cord to pull the sections together.
2. Attach the uprights to the base pushing in the spring buttons located on the base and sliding the pole over the bushing. Align the hole in the upright w/the spring button to lock in place.
3. Attach the crossbar to the uprights, from the outside in, using the screws provided.
4. Fasten graphic to the uprights by first inserting the fastener sleeve through the graphic, into the upright, then press the fastener pin fully into the sleeve until it locks into place. Repeat for the rear graphic (if applicable).
5. To remove connector, find the undercuts on the wide flat collar. Hold the upright with one hand and use fingernails of other hand to grab pin by the undercuts and remove the pin. If the sleeve doesn't come out, use fingernails or lightly pull on the graphic.

