

# SupraSlim SnapFrame™ - SUP Series

1. Place joiner plates into frame sides and tighten set screws to tighten joiner plate to secure frame sides.
2. Connect frame sides using corner brackets with set screws provided. Corner bracket with screws should be on top, bracket without screws should be below. Once corner brackets are in place, tighten screws.
3. Open the frame, then mount the frame to the wall using the pre-drilled holes on the frame.
4. Insert the graphic and snap the frame sides closed to secure the graphic.

