


Rigid Graphic Stand - SignPost System™ - YCL Series

1. Insert the knob/glide screw of the clamp into the slot of the upright at desired height.
2. Tighten the knob to secure position. Repeat with the knob/glide on the second upright, positioning at same height.
3. Repeat Steps 1 and 2 for the second clamp (not shown).
4. Open the clamp and insert the graphic into the clamp. Repeat for the second clamp.



Front-facing clamp



Side-facing clamp