

Portable Presentation Easel

Applicable Products:

425 426
425MG 427

1. Press down on hinges to open easel legs (fig. A).
2. Extend easel legs (fig. B) until push buttons lock into desired positions (fig. C).

