

Blade Poster SignHolder™ - BL Series

The 1-frame unit has a fixed frame pre-mounted to the upright pair. The 2-frame and 3-frame units have a split (2-section) upright pair, where the lower portion attaching to the base has a freely rotating frame(s), that is only fixed at the bottom of the frame.

1. **FOR THE 1-FRAME UNIT:** Slide the uprights (with fixed frame) over the stand-offs of the base. **FOR THE 2-FRAME AND 3-FRAME UNITS:** Identify the lower upright pair with the the free-rotating frame, and carefully lower the uprights onto the base stand-offs without allowing the rotating frames to get scuffed from contacting the ground.
2. Fasten the uprights to the base using the screws provided.
3. **FOR THE 2-FRAME AND 3-FRAME UNITS ONLY:** Lower the upper section of the uprights onto the lower uprights and fasten the uprights together using the screws provided.
4. **FOR THE 2-FRAME AND 3-FRAME UNITS ONLY:** Rotate the lower frame upward and insert the graphic into the top of the frame, then press the upper spring buttons on the uprights, and align the frame with the uprights. Release the upper spring buttons to allow the lower spring buttons to engage the holes on the side of the frame in order to lock the frame in place. Repeat this step for the additional lower frame on the 3-FRAME UNIT.
5. Insert the upper graphic into the top frame.

