

Stainless Steel Lock Instructions

1. Insert cable into plug.

Note: Be careful when handling the cable ends. if they're frayed, they can become very sharp.

2. Feed cable through the hole and into the second plug.

3. Press the plug to increase/decrease the size of the loop.

4. To remove cable, press the plug and pull the cable out of the lock (not shown).

