Perfex Menu System

1. Using a rubber mallet tap the four frames into the sides of the frame in the center of the display (Fig. A).

