- Push down on canvas tray to expand front legs (fig. A).
 Pull out back leg to expand easel (fig. B).





