

U Channel Stand™ - PLTCH, PXCH

1. Attach the upright to the base using the screw provided, as shown below.
2. Screw in the U-channel graphic holder to the top of the upright.
3. Insert the graphic into the U-channel, then tighten the small screws on the U-channel to secure the graphic.
4. Loosen the collar 1/4 turn counter-clockwise, raise the upper upright to the desired height, then tighten the collar 1/4 turn clockwise to secure the upright position.

