

Hand Sanitizer Gallon Stand - HSG Series

1. The bottom of the base has bumpers pre-installed. This bottom side faces the floor. Attach either end of the upright to the base using the flat head screws provided. It is normal for the screws to protrude slightly once fully tightened.
2. The Gallon holder plate is in two parts. Place the flat horizontal (the one with no bend) plate on top of the lip of the vertical plate (the one with a bend). Use the short round head screws to attach the plates to together by inserting the screws from the underside of the holes on the lip into the threaded holes of the horizontal plate. Tighten fully.
3. Place the plate assembly as shown in #3 below on top of the upright, and use the remaining flat head screws to attach the plate assembly to the upright. It is normal for the screws to protrude slightly once fully tightened.
4. Place the gallon container on the plate. The Velcro® Brand Fastener should go through one slot on the back plate, around the bottle, through the other slot on the back plate, and connect with the strap where it started. Tighten the strap fully.
5. Optional - The unit may include a steel cable and/or lock. To lock the bottle, loop the steel cable through the handle of the bottle (if one exists) and through the hole in the back plate. Join the looped ends of the securing cable using pad lock (if applicable).

